

- **How to set “Auto Close” on the terminal.**

Make sure “SETTLE”

MENU(Blue button)

-> Host Setting (#4)

-> PW 990712

-> Enter

-> Auto Dial Setup (#5)

-> Select Host(Omaha or Nashville(Nshvlltc)

-> Auto Dial Setup : 1(Off) or 2(On)

-> Press “2(on)”

-> Start AD At : put time(military time) 00/00

-> Enter

-> If not settled, Start AD at

-> Put Time (one hour after)

->Enter

-> AD Interval

-> 15

-> Enter

-> Cancel Button until main screen

- * **How to change Clock Time on Terminal**

MENU(Blue Button)

->System Setting(#5)

-> Date/ Time

-> Put Date: 03/01/2017

-> Enter

-> Put time :17:25(Military time)

-> Enter

-> Cancel Button until main Screen