

VX520 Technical Manual

I. How to change Date & Time (시간과 날짜 바꾸기)

II. How to unlock keyboard (키보드 락 풀기)

I. How to change Date & Time (시간과 날짜 바꾸기)

1. Press, **[Enter]**
2. Press, **[Set UP -F2]**
3. Put, Password (**1-alpha-alpha-66831**), then **[Enter]**
4. Press **[More]** Key **4 times**
5. Select **[Date & Time -F4]**
6. Key In Date (**MMDDYYYY**)
7. **[Enter]**
8. Set Time (Military Time Only)(**HHMMSS**)
9. **[Enter]**
10. **[Cancel]**(red button) **3 times** to get back to main screen



II. How to unlock keyboard (키보드 락 풀기)

From the Sale Refund Void screen

1. Press **[8]**
2. Enter password: [1 alpha alpha 6 6 8 3 1]
3. **[Enter]**
4. Lock Keyboard: Yes or No?
5. Select **[No- F2]**

